



1. remove the acrylic part from the brackets Attach the light struts to the middle brackets as shown in the drawing with M6x25mm hexagonal screws.



2. slide the lamp holder into the middle brackets and fix it with hexagonal screws M6x20mm and a washer 6x22mm, but do not tighten it completely yet.

3. mount a lamp on the lamp holder and place the shade on the holders to adjust the depth and height of the lamp.

You can adjust the depth with spacer plates.

Remove the visor and mount all lights.

Replace the visor on the brackets and tighten all screws.

