

1. Disconnect the cables from your trailer and remove the covers from the packaging.

2. Pull the cover partially over your cable. Make sure that the end of your sleeve and the end of your cable are at the same height.



3. Pull the cover over the entire cable and insert the fixing strips through the loops.



4. Tighten the strips so that the sleeves around the cable remain in place.