# **GloboFleet**®

User Manual Card Control



# **User manual | CardControl**



Many thanks for choosing GloboFleet CC software.

With GloboFleet CC you have a fast overview of remaining driving and working times based on the driver card data.

GloboFleet Card control software will automatically download and analyse the driver card as soon as you will put it into a card reader which is connected to your computer. At the end of the analysis you will see information about remaining driving and working times. The downloaded data will be stored locally on your computer.

#### Content:

Installation	. 3
Menu navigation	. 6
The toolbar	9
Overview:	
· Calendar1	12
· Driver card / Vehicle info	12
· Timeline	12
· Tables	13

### Installation | CardControl



Insert the GloboFleet CC CD into your DVD or CD-ROM-device.

The setup will start automatically.

A new window will be opened on your screen.

Click on the button "Next".

Now the Installer will ask you to confirm our terms of licence.

> Activitate the box "I agree" and click on the button "Next".






The GloboFleet CC Installer will now ask you to choose a storage location on your hard drive which is applicable for this software.

At this point you can also change the path for the installation directory.

Click on the Button "Choose" and afterwards you can confirm by clicking "Next".

### **Installation | CardControl**




The GloboFleet CC Installer will now install the Software on your system.

Just click on "Install".

The current window shows the installation process of GloboFleet CC software.






The system will now ask you to enter your serial number.

Please enter your serial number in the field "serial number".

Confirm your entry by clicking "OK".


### **Installation | CardControl**



The GloboFleet CC Installer will complete and finish the installation on your computer.

GloboFleet CC Software is then installed and automatically activated.


You are now able to analyse driver card and mass storage data.



- File > Open:
  - Opens any driver card file.
- File > Save Saves the displayed data in country-specific format (.ddd / .tgd / .v1b / .c1b).
- File > Send by mail Send the file you currently have open by email.
- File > Excel Export

Exports the opened file in a Microsoft Excel format. Select whether to save all recorded time periods or only the period you have chosen. You can also choose which contents you would like to save and if you would like to open the created files (Microsoft Excel needs to be installed).

- File > Print Prints out the current display. The standard print window of the system will appear.
- 6 File > Exit The programm will be closed



#### Archive > Data archive

Shows all archived files with recording start and end date. All files can be deleted, copied into a folder of your choice or sent by e-mail. You can sort the overview by driver or vehicle. The files will be archived when the card is read-out with the card reader, the downloadkey or in case you manually add files (see "File - save to archive").

### 2 Archive > Save to archive

The file you have currently opened will be copied into your data archive. This function is deactivated if the file already exists in the data archive.

### Archive > Send file

This function downloads external data from the GloboFleet data center and imports it into your local archive (for example the data you have transfered via the GloboFleet client). To use this function, you will need to purchase a pair of keys.

### 4 Archive > Deadline monitoring

The deadline monitoring shows the dates when driver or vehicles have to be read out or are overdue.



#### Extra > Card reader

You will see the card readers that are connected to your computer. This tool also shows you if the smart card is detected by the card reader.





Settings > Language

Change / set language of the software. The software can be used in one of the following languages English, German, Spanish, French, Portugese and Hungarian.

Settings > Timezone

Select in which format the data is to be saved in by default. This setting applies to the data you have downloaded from the card reader and also the predefined format in the save menu. You can also save an opened file in another format.

- Settings > Standard file format
  - Legt fest, in welchem Dateiformat die Daten der Fahrerkarte gespeichert werden.
- Settings> General Settings

Here you can specify whether you want the software to ignore any existing double periods, incomplete files or signature error. Next you can set whether the data read from the download key should be transferred to a subdirectory (\ Downloaded) in the downloadkey. (This setting is enabled by default)

Settings > Regulations

Eln addition to the european regulation you can also select the swiss regulations. Select between "Regulation EC No. 561/2006", "Chauffeur regulation ARV 1 (Lorry)", Chauffeur regulation 1 (Bus)", "Chauffeur regulation ARV 2 (regular)" and "Chauffeur regulation ARV 2 (Taxi)".

Settings > File archive

In this menu you can select the target folder and time period you would like to archive.

Settings> Schedule overview

Here you can select according to which periods the schedule overview manages the dates administered.

Settings > File transfer

Configure the settings for access to the GloboFleet data center. This is required for using the GloboFleet Client. (Here you can purchase the pair of keys needed)

Settings > Mail Settings

If you do not want your data from the software to be sent with the GloboFleet e-mail service but with your own email account you can make your e-mail settings here.

Settings > GloboFleet Service

Starts and stops the GloboFleet Service. This tool checks the card reader and the USB-ports and will start the program automatically as soon as you have plugged in a driver card or a downloadkey with tachograph data. A small tachograph symbol will appear in your task bar if you have started this service. Green traffic light: Service is active, Red traffic light: Service is disabled, Yellow traffic light: Service is starting/stopping

Settings > Proxy server

When using a proxy server to connect to the Internet, you must configure it in this menu or otherwise you will not able to load updates or send e-mails. If necessary, ask your system administrator which data has to be entered here. In addition to the proxy-server-settings in the software you will also need to enable port 12000 on your server (Domain: update.globofleet.com, protocol; SOCK5 - socket connection).



### Help > About

Shows information about the software version. It will also show information about your system.

### 4 Help > Online help

All features of the software are explained here.

#### Help > FAQ

Frequently asked questions can be found here.

### 4 Help > GloboFleet

HYou will be forwarded to the GloboFleet manufacturer site.

#### Help > Remote control

With this function the GloboFleet support team is able to set up a remote connection to your computer and is then able to detect and eventually solve problems directly.

### Help > Check updates

Shows all available updates. You can download and install available updates.

### Help > Automatical updates

If this function is activated, available updates will be downloaded and installed automatically.

#### Help > Serial number

Enter here your serial number to enable the functions of the full version.

#### Melp > Registration

You need to register your software in order to receive updates and our newsletter.

# The toolbar | CardControl



### Open file

Opens any driver card or tachograph file.

- Save file
  - Saves the displayed data in country-specific format (.ddd / .tgd / .v1b / .c1b).
- Opening the state of the sta

Shows all archived files with recording start and end date. All files can be deleted, copied into a folder of your choice or send by e-mail. You can sort the overview by driver or vehicle. The files will be archived if you transfer these with the card reader, the downloadkey or in case you manually add files (see ..File - save to archive").

Save to archive

The file which is currently opened will be copied into your file archive. This function is deactivated if this file was copied to the file archive before.

Transfers files which not have been uploaded to the GloboFleet data center.

O Deadline monitoring

The deadline monitoring shows the dates when driver or vehicles have to be read out or in case they are overdue.

Send by e-mail

You can send the currently opened file by e-mail.

© Excel exportieren

Exports the opened file into the Microsoft Excel format. You can choose wheather to save all recorded time periods or only the period you have chosen. You also can chosse which contents you would like to save and if you would like to open the created files (Microsoft Excel needs to be installed).

Print

Prints out the current overview. The standard print window will appear.

Oheck for updates

Shows all available updates. You can download and install available updates.

# The toolbar | CardControl



### File name display

The path of the currently opened file will be displayed. If you open a file out of the file archive, the name begins with "file archive".

#### Time zone

You can choose if you would like to see the time periods calculated in Greenwich mean time or local time. This setting has no influence on the violation analysis as social violations are generally calculated according to Greenwich mean time.

### Language

Change / set language of the software. You can use the software in English, German, Spanish, French, Portugese and Hungarian.

### Timeline

The saved activities are shown as a graphic in chronological order.



# Overview | CardControl

#### Driver card information

General information which are stored in the file are mentioned in this overview.

#### 2 Calender

In the calender you can choose the selected time period. If you click on the name of the month, the complete month will be selected, a click on the calender week will show the whole week. If you click on one day, you also can look at a single day. If you use Shift + click you can increase or decrease the selected period. The time period you have currently selected, will be displayed in light blue. With the arrow keys you are able to turn over pages. Alternatively you can use the mouse wheel to turn pages.


#### **Tables**

The data saved in a file or the data which are calculated based on this data, are displayed as a table. These tables are very similar, the only exceptions can be found in the tables remaining time and controls: For these two tables the following does not apply: The displayed data are always depending on the selected time period (see calender and time period). If you click or drag the mouse, you can select a time period (see **Time period / selection**).



### Table: Remaining time

The software will show the measured remaining time at the time of data download. The determined, allowed and the remaining time resulting out of this data will be displayed. If an allowed value falls below or exceeds a permissible value the line will be marked in red. If any value can not be reached anymore (due to recorded data, for example team drive), the line will be crossed out.



### Table: Events

The events saved in the file will be shown here. The table gives you more information about the data, time period, duration, group and a description of the event.



#### **Table: Errors**


The errors saved in your file will be shown in this overview. The table gives you information about the date, time period, duration, group and a description of the error. In addition you will see information about the used vehicle.



#### **Table: Controls**


This shows the controls saved in your driver card. In addition to the control date, card number and type the table informs you if driver card or tachograph store was read-out. It also mentions if the data were displayed or printed.

You also will see information about the used vehicle.



#### **Table: Vehicles**

All used vehicles which are stored in your file are displayed here. The table includes information about time period, duration, number plate, mileage at start, mileage at end, driven distance.



### **Table: Activities**


This shows the activities of your driver and activities without driver card. The table informs you about time period, duration and kind of activity. You also see information about the countries passed through, the name of the driver and driving method (Single, Team, Team co-driver) and driver card status (card inserted, manual bookings, unknown).

If a special case (out of scope, ferry ride) falls into the time of an activity, this is shown with the activity-symbol. Please see more information about that in "Table: Special cases".



#### **Table: Countries**

The country information stored in this file are shown here. The table gives you information about date, country, mileage and kind (start or end) of recording.



### Table: Special cases

All recorded special cases are shown here. Special cases for example are ferry rides or out of scope times (Beyond the scope of useage). The date and kind of special case are displayed.



### **Table: File Content**

In this table you find information about the completeness and the content of the downloaded file.





4260179020179

### **SWIFT DECISION LIMITED**

40 ROUNDFIELD AVENUE AL5 5BE Harpenden United Kingdom

### Help / Support

Support: +44 (0)203 3181117 E-Mail: mail@globofleet.co.uk Internet: www.globofleet.co.uk



© 2014 Buyond GmbH, Alle Rechte vorbehalten