RF Wireless Remote

Instructions

- Dimmer & Dynamic
- 8 Dynamic Effects
- 10-Level Dimmer
- 256-Grade PWM •
- Speed Adjustable
- Card Type Remote
- Ultra Slim Design
- 1 to 1 Remote Paired
- Auto Save Function

Functions

1.Turn On/Standby

Press this key to turn on unit or switch to standby mode. Unit will turn on and restore to previous status at powering on moment

2. Lighting mode

Switch to lighting mode from dynamic mode.

3/8/9. Dimmer Adjust Shortcuts

Switch to 100%, 50%, or 25% brightness lighting mode.



- Smooth Dimmer Effect

Functions

4/6. Dynamic Mode Adjust

Switch to dynamic mode from lighting mode, or switch between different dynamic modes.

5/7. Speed Adjust

Adjust playing speed of dynamic modes. Press SPEED+to increase speed and press SPEED- to decrease.

10/11. Brightness Adjust (Dimmer)

Adjust lighting mode brightnes. Press BRIGHT+ to increase brightness and press BRIGHT- to decrease.

